

**INSTALLATION INSTRUCTIONS  
HARLEY DAVIDSON FXD (DYNA) 1994 & NEWER  
PASSENGER FLOOR BOARDS #FXD005  
AND RELOCATION ARMS #FXD005-5**

*If you have Passenger Floorboards #FXD005 and are adding  
Relocation Arms #FXD005-5 refer only to steps 5 & 10.*

1. Beginning on the RIGHT side, use a 9/16" wrench to remove the bolt from the back of the passenger peg mount. Remove entire peg assembly.
2. Remove the new floorboards and mounts from their packaging. Notice the Left and Right markings on the backside of the floorboard mounting plates.
3. Install the supplied Right floorboard support (the longer one) with the round mounting face for the floorboard towards the upper-right using the supplied 7/16 x 1 1/4" long bolt. Apply blue Loctite to the threads. Insert the bolt from the backside where the original peg was mounted. Use a 5/8" wrench & tighten securely.

**Note: If also installing with optional Relocation Arms (#FXD005-5) skip step 4 and go onto step 5.**

4. **Installation of Right Floorboard only.** There are two sets of alignment holes on the floorboard support. Insert two of the four dowel-pins into the dowel pinholes at six and twelve o'clock. Place the right floorboard onto the mount and dowel pins so that it is parallel (horizontal) to the ground. Insert the supplied 5/16 X 1" socket head cap screw through the floorboard mount & thread into the floorboard support. Use a 1/4" hex key wrench & tighten securely.
5. **Remove Right Floorboard - Installation of Right Floorboard with Relocation Arm.** There are two sets of alignment holes on the floorboard support. Insert two of the four dowel pins into the dowel holes 180 degrees apart. Notice the L & R markings on the backside of the relocation arms. Install the Right relocation arm so marking (R) is facing inward and the threaded hole is facing toward the front of the motorcycle. There are two sets of alignment holes on the relocation arms. Place the arm onto the mount (Match dowel pin holes) in desired upper or lower position. Insert the supplied 5/16 X 1" socket head cap screw through the relocation arm & thread into the floorboard support. Use a 1/4" hex key wrench & tighten securely.
6. At the other end of the relocation arm there are two sets of alignment holes. Insert two of the supplied dowel pins into the set of dowel pin holes 180 degrees apart that will allow the floorboard to be horizontal or parallel to the ground. Insert the supplied 5/16 X 3/4" socket head cap screw through the floorboard mount & thread into the link arm. Use a 1/4" hex key wrench & tighten securely.

**INSTALLATION INSTRUCTIONS**  
**HARLEY DAVIDSON FXD (DYNA) 1994 & NEWER**  
**PASSENGER FLOOR BOARDS #FXD005**  
**AND RELOCATION ARMS #FXD005-5**

7. Remove the Left foot peg and mounting block assembly. To do this you must first remove the black vertical arm that the peg assembly is bolted to. Looking under and behind the engine locate the socket head bolt which secures the arm to the frame, remove the bolt using a 5/16" hex key wrench and remove the arm and foot peg assembly. Using the same 5/16" hex key wrench remove the left passenger peg and mount assembly from the back of the arm. Slide the arm back in place temporarily.
8. Place the Left floorboard support (shorter of the two) with the round mounting face for the floorboard towards the upper-left onto the arm. Locate the supplied 7/16" X 1 1/4" socket head cap screw. Apply blue Loctite. Install the bolt making it snug. Remove the arm assembly and tighten securely using a 3/8" hex key wrench. Reinstall the arm and its mounting bolt, tightening the bolt securely.

**Note: If also installing with optional Relocation Arms (#FXD005-5) skip step 9 and go onto step 10.**

9. **Installation of Left Floorboard only.** There are two sets of alignment holes on the floorboard support. Insert two of the four dowel pins into the dowel pinholes at six and twelve o'clock. Place the right floorboard onto the mount and dowel pins so that it is parallel (horizontal) to the ground. Insert the supplied 5/16 X 1" socket head cap screw through the floorboard mount & thread into the floorboard support. Use a 1/4" hex key wrench & tighten securely.
10. **Remove Left Floorboard - Installation of Left Floorboard with Relocation Arm.** There are two sets of alignment holes on the floorboard support. Insert two of the four dowel pins into the dowel holes 180 degrees apart. Notice the L & R markings on the backside of the relocation arms. Install the Left relocation arm so marking (L) is facing inward and the threaded hole is facing toward the front of the motorcycle. There are two sets of alignment holes on the relocation arms. Place the arm onto the mount (Match dowel pin holes) in desired upper or lower position. Insert the supplied 5/16 X 1" socket head cap screw through the relocation arm & thread into the floorboard support. Use a 1/4" hex key wrench & tighten securely.
11. At the other end of the relocation arm there are two sets of alignment holes. Insert two of the supplied dowel-pins into the set of dowel pin holes 180 degrees apart that will allow the floorboard to be parallel (horizontal) to the ground. Insert the supplied 5/16 X 3/4" socket head cap screw through the floorboard mount & thread into the link arm. Use a 1/4" hex key wrench & tighten securely.