

**FRONT TURN SIGNAL RELOCATION
HARLEY DAVIDSON FXD (DYNA)
INSTALLATION INSTRUCTIONS #FXD104**

1. Use a 5/8" wrench to remove turn signal mount from bottom of mirror stud. Be sure to hold signal housing stationary while removing mount to prevent wire damage. Use a 1/2" wrench to remove signal mounting from housing.
2. Install supplied 5/16" screw into signal relocater clamp halve and place supplied 1/2" diameter spacer over threaded end of screw. Use a 5/32" hex key wrench to mount signal to clamp halve and tighten securely. Use caution not to over-tighten and crack the signal housing. Signal should be mounted at a 30-degree angle as shown in photo #1.
3. Locate the opposite clamp halve and 2 of the supplied #10 screws. Place the assembled signal/clamp halve onto the top of the fork/steering triple clamp as shown in photo #2. Use a 5/32" hex key wrench to mount the clamp halve to signal assembly making sure of zero air gap in the front of the clamp assembly as shown in photo #2 and tighten securely.
4. Use the supplied cable ties to neatly secure the turn signal wiring.

RIVCO Products, Inc.
440 S. Pine St. Burlington, WI 53105
262-763-8222 www.rivcoproducts.com