

GL18005 Passenger Floor Board Risers Installation Instructions

Flip the passenger floorboards in the up or closed position.
Remove the four (4) allen bolts that attach them to the frame.

Install the carriage bolts (round heads) into the backside of the risers (side opposite of recess for mounting screws). Then the plastic washer, next the floorboard, then a washer, lock washer and nut but do not tighten yet. Install the riser floorboard assembly back onto the frame using the original allen bolts and placing the aluminum spacers between the risers and the frame, tighten securely.

Note: the curved slots should sweep up and back towards the rear of the motorcycle. You may reverse the left and rights so that the slots curve forward to gain further forward placement of the passenger's feet if desired.

Set floorboards to desired height and tighten securely.

**Rivco Products, Inc.
440 South Pine St.
Burlington, WI 53105
(262) 763-8222
www.rivcoproducts.com**