

Billet Aluminum Highway Board
HBPB

1. These Highway floorboards are designed for use with Rivco highway mount clamp and arm sets. Other brands may require additional hardware. Notice that there is a left and right, when installed the heel should be in closer and the toe angled outward.
2. Place a split lock washer and then the larger washer supplied onto each of the bolts. Install the bolt thru the hole of the highway mounting arm from the backside and the threaded end of the bolt pointing towards the outside. Place one of the serrated lock washers onto each of the bolts, then the highway floorboard followed by the remaining thin washers and acorn nuts. Position the highway floorboards to the desired angle and tighten the mounting bolts and nuts securely.
3. Fold the highway floorboards up and notice the small Allen screw just above the acorn nut. This Allen screw can be adjusted out as desired to tip or angle the boards back toward the rider for added comfort. These screws are held in place with a thread locking compound, when adjusting work the screw in and out slowly to loosen the thread locker until the screw rotates as desired.

Rivco Products, Inc
440 S. Pine St.
Burlington, WI. 53105
262-763-8222