

ADJUSTABLE PASSENGER FLOORBOARDS  
FOR HARLEY-DAVIDSON fits 1980 & NEWER FLT's, FLHT's, FLTR's  
AND 1986 & NEWER HERITAGE SOFTAILS  
#HD005A

1. Layout the parts as shown in photo #1. Note: The left and right floorboard assemblies are marked on the back side, also note the markings and roll pin locations on the mounting blocks see photo #1A. The right mount has the pin in the hole stamped R and the left has the pin in the unmarked hole.
2. Remove the stock passenger boards by removing the 3/8" allen bolts securing them to the frame. Save the allen bolts and washers as they will be reused later.
3. Beginning on the left side see photo #2, place the left mounting block (the one with the pin in the unmarked hole) onto the frame placing the pin into the lowest unthreaded hole. Using the bolt and lock washer from the original floorboards saved earlier, bolt the mounting block to the frame and tighten securely.
4. Insert two (2) of the 5/16 allen bolts provided into the holes of the triangular base of the left floorboard assembly. Bolt the floorboard assembly onto the mount with the point of the triangular base facing towards the rear of the motorcycle see photo #3. Thread the bolts into the holes evenly to prevent the heads from marring the link arm. Tighten securely. Pull the spring loaded pin on the link arm see photo #3A and rotate the floorboard and link arm assembly to the desired position, allow the pin to drop into the hole closest to the desired position.
5. On the right side install the mounting block (the one with the pin in the hole marked "R") with the pin facing downward and in the lowest unthreaded hole. Bolt it on securely using the original bolt and lock washer.
6. Complete the installation the same as on the left.

Thank you for purchasing a RIVCO American Made product.

RIVCO Products, Inc  
440 South Pine Street  
Burlington, WI 53105  
rivcoproducts.com  
262.763.8222

