

**Caliper Cover for Harley-Davidson
Installation Instructions #HD030**

1. Clean caliper face with rubbing alcohol making sure it is free of grease, oil & debris.
2. If the caliper is below 70 degrees warm it with a hair dryer.
3. Peel the self-adhesive backing and press into place firmly and hold for 30 seconds.

RIVCO Products, Inc.
440 South Pine Street Burlington, WI 53105
262-763-8222 rivcoproducts.com