

**DRIVER PEGS HONDA ADAPTOR
INSTALLATION INSTRUCTIONS
#PEGSHA**

1. Assemble the peg onto the peg adaptor by removing the allen bolt from the end of the foot peg you are using. Remove the clevis assembly (folding mechanism) from the peg itself. Assemble the peg and allen bolt on to the peg adaptors.
2. The original peg pivots or folds up on a pin and has a return spring. Note how the spring is assembled into the peg. Remove the cotter pin, washer and pivot pin and foot peg. Install the new peg and adaptor assembly onto the motorcycle in the same manner and using the same spring, pin, washer and cotter pin. Set the angle of the new peg as desired and tighten the allen bolt securely.
3. Use the small set screws located at the end of the adaptors to raise and lower the foot pegs resting position.

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
rivcoproducts.com
262.763.8222