

**RELOCATION ARMS
FOR SUZUKI M109 PASSENGER FLOORBOARDS
#SM9005-5**

1. If you are installing the relocation arms at the same time as the floorboards follow their instructions first and then refer to this sheet.
2. Fold the floorboards up, remove the allen screws that attach them to the round spacers, remove the floorboards and set aside.
3. Install the left and right relocation arms (marked with an L and R on the back side) onto the pins of the round spacers in the upper or lower position as desired. Using the allen screws and washers supplied bolt the arms to the round spacers and tighten securely.
4. Re-install the floorboards onto the relocation arms placing the supplied dowel pins into the set of holes on the relocation arms that allow the floorboards to be level or parallel with the ground. Install and tighten the allen screws removed earlier.

RIVCO Products, Inc
440 S. Pine St.
Burlington, WI. 53105
Ph. 262-763-8222