

INSTALLATION INSTRUCTIONS
CALIPER COVER FOR TRIUMPH AMERICA & SPEEDMASTER
#TA030

1. Clean caliper face with rubbing alcohol making sure it is free of grease, oil & debris.
2. If the caliper is below 70 degrees warm it with a hair dryer.
3. Peel the self-adhesive backing and press into place firmly and hold for 30 seconds.