

**CORBIN SADDLEBAG SUPPORTS #TR3005-6  
FOR TRIUMPH ROCKET III**

**These brackets will allow the use of Rivco passenger floorboards and relocation arms with Corbin saddlebags**

1. Remove the 9/16" bolts from the lower saddlebag support brackets located inside the bottom of the saddlebags.
2. Remove the passenger foot pegs and saddlebag mounting brackets by first removing the pegs pivot bolts and nuts then the 12mm nuts from the backside of the pegs.
3. Install the new saddlebag mounting brackets reusing the bolts inside the saddlebag. If you are installing floorboards and relocation arms use the 5/16" X 2 1/2" hex bolts supplied in place of the one supplied with the relocation arms to bolt the brackets and arms to the motorcycle. If you are installing floorboards only use the 5/16" X 3" socket head bolts supplied in place of the one supplied with the floorboards to bolt the floorboards and saddlebag brackets to the motorcycle.
4. Follow the instructions for the relocation arms and or floorboards.

**RIVCO Products, Inc**

440 S. Pine St.      Burlington, WI. 53105  
Ph. 262-763-8222      [www.rivcoproducts.com](http://www.rivcoproducts.com)