

DRIVE SHAFT COVER INSTALLATION INSTRUCTIONS
TRIUMPH ROCKET III # TR3016

1. Peel the backing from the adhesive tape on the inside of the cover. Hook one end of the springs into the small holes on the top of the cover so that the open end of the springs hook faces the outside of the cover. Carefully set the cover in place and press firmly to secure the tape. Using a needle nose pliers stretch the springs and hook them into the lower holes on the cover.
2. Set the small flat cover in place on the topside of the swing arm next to the driveshaft cover and note its position. Clean the area using rubbing alcohol, peel the backing from the cover, set in place carefully and press firmly.

RIVCO Products, Inc
440 South Pine Street Burlington, WI 53105
262.763.8224 rivcoproducts.com