

**TRIUMPH ROCKET III LICENSE RELOCATION BRACKET  
INSTALLATION INSTRUCTIONS #TR3105**

1. Remove the seat using the ignition key in the seat lock (photo 1A). Remove the two 10mm bolt (photo 1B), which secure the right side cover. Remove the right side cover (lift upward t the front then pivot towards the rear).
2. Locate and unplug the four turn signal wires (photo 1C). Notice the red tape near the connectors on one set of the wires. These are the right signal wires.
3. Looking up under the rear fender bend down the seven wire clips which hold the tail & turn signal wires up against the inside of the fender. Pull the wires down away from the clips. Using a blade screwdriver open the plastic clip located behind the frame tube that secures the wires (photo 1D). Pull the signal wires out from behind the frame tube, rear shock absorber & back to the turn signals.
4. Looking up under the rear fender locate and remove the four 10mm nuts which secure the license/signal mounting bracket to the rear fender. Remove the bracket, license and turn signal assembly from the rear fender by pulling down on the fenders inner brace far enough to allow it to slide out from the four mounting studs. (It may be helpful to have another person assist you with this step.) Using a towel or rug to protect it lay the assembly on the floor face down next to the rear wheel (the license light wires will still be attached.)
5. Remove the two 10mm bolts from the license light (photo 2A). Remove the two 14mm nuts from the turn signal stems (photo 2B), slide the nuts and washers off the wires and remove the signals and their wires from the bracket NOTE: lay them out and keep them on the same side as you removed them from. Remove the license plate from the bracket.
6. Lay-out the new bracket in place of the old one and reassemble the license plate (Using the lower holes will mount the plate as high as possible (shown), using the upper holes will mount it 2" lower). Reassemble the turn signals onto the bracket (be sure the signal with the red tape at the end of the wires is on the left side when the license plate is facing away from you as shown) and license light onto the new bracket. Reassemble the license light onto the bracket.
7. Reinstall the assembly back onto the fender, install the four 10 mm nuts and tighten. Reroute all the wires up into one clip at a time beginning at the bracket and bend them closed. Do this with all seven clips. Route the wires thru the plastic clip behind the frame tube and close the clip. Plug the wires back into the wire harness Note: the set of signal wires with the red tape goes to the set from the harness that also have the red tape, the black wires go to the black wires and the white wires go to the green wires. Turn on the ignition and check the function of the signal and license plate lights. Reinstall the side cover and seat. Recheck that all the wire and fasteners are secure and tight.

**RIVCO PRODUCTS**

440 South Pine Street Burlington, Wi. 53105  
262-763-8222 rivcoproducts.com

