

**INSTALLATION INSTRUCTIONS**  
**VALKYRIE ADJUSTABLE PASSENGER BOARDS**  
**#VAL005A**

**NOTE:** You must have the stock black foot peg/muffler mounting plates to use these floorboards. If you have the Hondaline® chrome foot peg/muffler mounting plates the foot peg extension is welded to the plate. You can either go back to the original black plates or grind the weld from the backside and remove the peg extensions.

1. Remove the stock pegs using a 14mm wrench on the backside of the peg and muffler mounting plate. NOTE: use the box end of the wrench as these bolts are very tight from the factory.
2. Loosen the two (2) 12mm acorn nuts that attach the mufflers the mounting plate on each side. Next remove two (2) 14mm bolts that attach the plates to the frame on each side.
3. Install the floorboards using the new bolts provided and tighten securely. Tighten the 12 mm acorn muffler mounting nuts on both sides.
4. Pulling the spring-loaded levers out and rotating the lever slightly to hold it in the out position can adjust the Boards. Adjust to the height desired; rotate the levers back to line up with the slots, rock the board and arm slightly so that the spring-loaded pin drops into the nearest hole.

Thank you for purchasing a RIVCO product.