

VTX1800 & VTX1300 PASSENGER BOARDS
INSTALLATION INSTRUCTIONS
#VTX005 & #VTX13005

- Remove the cotter pins, washers and pivot pins from the stock foot pegs, then remove the peg.
- Install the floorboard assembly into the foot peg mounting brackets using the provided hardware. (NOTE: the boards are marked Left and Right) Put the bolt thru the hole with the head of the bolt facing the front of the motorcycle. On 1800C models you will need to place one of the washers removed earlier between the floorboards mounting block and the “U” shaped peg mount bracket on the frame. This will fill the additional clearance on this model. Next install the washer and nut onto the bolt and tighten securely.
- Check the button head allen bolt that mounts the Rivco passenger board pivot assembly with a 7/32” allen wrench to be sure that it is tight.

We offer an optional set of link arms (part no #VTX005-5), which will relocate the boards 3.5” farther forward. These are extremely beneficial to passengers with long legs and for motorcycles fitted with any saddlebags which cramp the passenger’s foot rest area.

RIVCO Products, Inc. 440 South Pine Street Burlington, WI.
262.763.8222 www.rivcoproducts.com