

**VTX1800 & 1300 LINK ARM
INSTALLATION INSTRUCTIONS
VTX005-5**

- 1. If you are installing the link arms at the same time as the passenger floorboards first install the floorboards per their instructions.**
- 2. Fold the boards up in the retracted position. Remove the allen screws that secure the boards to the black mounting blocks & remove the boards. Note there are two dowel pins between the mounts and the backside of the boards, remove these dowel pins and place them in the holes in the link arms.**
- 3. Place the link arms onto the black mounting blocks: Note the cutout on the back of the link arm; this engages the edge of the black mounting blocks. (The link arms should face forward and curve upward.) Install the allen screws and washers removed earlier & tighten securely.**
- 4. Place the dowel pins removed earlier into the holes in the link arms. Place the floorboard assemblies onto the link arms. Install the allen screws and washers provided and tighten securely.**

RIVCO Products, Inc.
440 S. pine St. Burlington, WI. 53105
Ph. 1-262-763-8222
rivcoproducts.com