

**SWING ARM COVER FOR HONDA VTX 1800 & VTX1300
INSTALLATION INSTRUCTIONS
#VTX015 & VTX13015**

1. Remove the two (2) 6mm bolts holding the brake hose clips in place.
2. Slide the cover in from the rear over the swing arm and align the holes. (NOTE: on Retro models and some aftermarket exhausts it is necessary to remove the two (2) muffler mounting bolts and loosen the two (2) exhaust nuts on the rear cylinder head then pull the exhaust outward to gain clearance to slide the cover into position).
3. Replace the original front bolt or bolts into the cover and hose clip. NOTE: the hose clip should go behind the chrome cover and it may be necessary to straighten out the bend in the clip slightly to gain alignment of the holes. Replace the rear bolt with the one supplied and tighten both securely.
4. Replace and tighten the exhaust bolts if removed earlier.

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
262.763.8222
www.rivcoproducts.com