

VTX 1800 CHROME RADIATOR COVER
PART# VTX020

1. Remove the amber reflectors from the sides of the stock plastic radiator cover. These can be pried off carefully using a wide screwdriver blade or small putty knife.
2. Remove the 3 allen screws from the stock plastic radiator cover, 2 on top and 1 on the bottom.
3. Slide the chrome radiator cover over the stock plastic cover.
4. Re-Install the two original upper screws into the top holes. In the bottom hole install the button head allen screw and washer provided. Tighten all three screws. Firmly press the reflectors back onto the chrome cover.

Thank you for purchasing a RIVCO Product.

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
262.763.8222 rivcoproducts.com