

VTX1300 FRONT FENDER BUMPER
INSTALLATION INSTRUCTIONS
VTX13011F

1. Carefully slide the bumper up into position (it will be necessary to flex the bumper inward to get the brackets over the fender mounting bolts).
2. Remove the 2 front bolts and replace them with the longer bolts supplied and next replace the 2 rear bolts. Tighten all 4 securely.
3. Install the 4 nuts supplied, before tightening peel the backing from the clear bumper supplied and stick it to the fender behind the center of the lower chrome front bumper rail, center the bumper left to right while keeping it down against the rubber bumper on the fender and tighten the 4 nuts securely.

RIVCO Products, Inc.
440 South Pine Street
Burlington, WI 53105
262.763.4281
rivcoproducts.com