

VTX1300 RADIATOR COVER
INSTALLATION INSTRUCTIONS
Part # VTX13020

1. Remove the upper radiator cover bolts.
2. Hook on lower edge of chrome cover over existing radiator cover.
3. Align upper holes with existing holes.
4. Replace bolts.

RIVCO Products Inc.
440 South Pine Street
Burlington, WI 53105
262.763.8222
rivcoproducts.com