

**HONDA VTX1300 “C” MODEL
HANDLEBAR RISERS PART #VTX13C017
INSTALLATION INSTRUCTIONS**

NOTE! Polished aluminum risers can become scratched very easily!
Handle risers with extreme care. Use wax and a soft cloth
to clean risers and prevent oxidation. (Becoming dull)

1. Lay a blanket folded several times over the fuel tank to protect it.
2. Remove from underneath, the two hex nuts holding the handlebars to the upper triple clamp. (Steering head) Remove handlebars & carefully set on blanket.
3. *NOTE: Be careful not to scratch the upper triple clamp when installing the new risers.* Assemble the supplied lock washers and flat washers onto the supplied bolts. Install the new risers onto the triple clamp and finger-tighten the bolts.
4. Re-install the handlebars onto the risers & finger tighten the nuts. Align handlebars & risers to be parallel & centered. Tighten the two riser-mounting bolts securely. Tighten the handlebar mounting nuts securely. Check for adequate clearance and proper routing of cables and hoses.

Rivco Products, Inc

440 South Pine Street Burlington, WI 53105
262.763.8222 rivcoproducts.com