

**VTX 1300 & 1800 RETRO DRIVER BOARDS
INSTALLATION INSTRUCTIONS #VTXR024**

1. Remove the stock driver boards. Looking underneath the boards locate the pins on which the boards pivot. Remove the circlips and washers. Slide the pins out and remove the board from its mount. Note how the spring is installed.
2. Place the new board onto the mount. Slide the pin thru one side of the mount and board. Next install the spring into the open area. NOTE: the spring leg with the bent end should go into the slot or pocket on the board. Push the pin thru the spring's center hole. Using a screw driver rotate the other leg of the spring up onto the black mount. Continue pushing the pin the rest of the way thru the board and black mount. Re-install the washers and circlips.

Thank you for purchasing a RIVCO product.

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
262.763.8222
rivcoproducts.com