

**KAWASAKI VULCAN 1500, 1600, 2000  
HANDLEBAR RISERS PART #VUL017  
INSTALLATION INSTRUCTIONS**

1. Lay a blanket folded several times over the fuel tank to protect it.
2. Loosen (do not remove) from underneath, the two hex nuts holding the risers to the upper triple clamp. (Steering head)
3. Remove the four handlebar clamp bolts. (8mm allen wrench)  
While sitting on the motorcycle, pull the handlebars and upper clamp off of the risers. They may be slightly stuck and require some force to get free. Lay the handlebar and/or upper clamp/gauge assembly carefully on the blanket.
4. Remove the nuts and risers from the triple clamp. *NOTE: Be careful not to scratch the upper triple clamp when installing the new risers.* Assemble the supplied lock washers and flat washers onto the supplied bolts. Install the new risers onto the triple clamp and finger-tighten the bolts.
5. Re-install the handlebars and upper clamp/gauge assembly. Tighten the front bolts first closing the gap at the front, and then tighten the rear bolts. Tighten the two riser-mounting bolts securely. Check for adequate clearance and proper routing of cables and hoses.

**RIVCO Products, Inc**

440 South Pine Street  
Burlington, WI 53105  
262.763.8222  
rivcoproducts.com