

YAMAHA ROAD STAR (all years)
PASSENGER FLOORBOARD RELOCATION ARMS
#XV17005-5
INSTALLATION INSTRUCTIONS

1. If you are installing Relocation Arms and Passenger Floorboards, install the floorboards first per their instructions. When installing the Relocation Arms with Passenger Floorboards already installed proceed as follows.
2. Starting on the LEFT side, fold the floorboard up. Remove the socket head bolt which secures the floorboard to the motorcycles stock peg support and remove the floorboard taking notice of which pinholes the dowel pins are located in.
3. Locate the Relocation Arm that has an “L” stamped on the backside of it. Place two of the supplied dowel pins into one of the two sets of the pinholes in the backside of the arm that are directly across from one another. (180 degrees apart.) Place the arm onto the mounting block and align the pins in the arm with the holes closest to the desired height you wish the floorboard to be at. Bolt the arm to the mounting block loosely using one of the supplied 5/16” X 1” button head bolts.
4. Place the Passenger Floorboard with its two dowel pins into the set of pinholes at the other end of the relocation arm that allows the floorboard to be parallel (horizontal) to the ground. Use one of the supplied 5/16” X 3/4” socket head bolts to mount the floorboard to the relocation arm and make finger tight.
5. Install the RIGHT side in the same manner. Check to see that the right arm is at the same height and/or position as the left. Bolt the floorboard to the other end of the arm using the remaining dowel pins and socket head bolt. Tighten all four bolts on both sides securely.

NOTE: Four other height positions are possible by using the other sets of holes on the front side of the mounting block and backside of the relocation arm.

Rivco Products, Inc.
440 S. Pine St. Burlington, WI. 53105
Ph. 262-763-8222
rivcoproducts.com