

YAMAHA ROAD STAR (all years)
PASSENGER FLOORBOARDS #XV17005
INSTALLATION INSTRUCTIONS

- **Note: if you are installing #XV17005-5 Relocation arms at the same time as the floorboards follow these instructions first then refer to the relocation arm instructions.**
- 1. Remove the two 8mm socket head screws from the passenger foot peg mounts on each side & remove the passenger peg sets.
- 2. Starting on the left side locate the left floorboard mounting block. (Stamped with an "L" on the backside). Bolt the mount to the frame with the floorboards mounting hole toward the top or facing upward using two of the supplied M8 X 45mm socket head bolts & tighten securely. Insert two of the supplied 3/16" X 1/2" dowel pins into the two holes closest to six & twelve o'clock on the mounting block. Locate the left floorboard assembly. (Stamped with an "L" on the backside.) Place the floorboard onto the mount engaging the dowel pins so that it is level or parallel to the ground. Attach the floorboard to the mount using one of the 5/16" X 1" socket head screws supplied & tighten securely.
- 3. Install the right side mount & floorboard in the same manner.
- 4. If you are also installing the VX17005-5 relocation arms, follow those instructions next. Finally be sure to tighten all bolts securely.

Rivco Products, Inc

440 S. Pine St. Burlington, WI. 53105

Ph.262-763-8222

rivcoproducts.com