

PASSENGER FLOORBOARD RELOCATION ARMS FOR
YAMAHA ROADLINER AND STRATOLINER ALL YEARS
XV19005-5

1. When installing floorboards at the same time first refer to their instructions and using the longer right side black floorboards mounting block supplied with this set of relocation arms. Leave the final floorboards mounting bolt installed loosely at this time.
2. If installing the relocation arms after installing the floorboards at an earlier date proceed as follows.
3. On the left side remove the Allen screw below the floorboards pivot and remove the floorboard from the black mounting block. Remove the dowel pins from their holes on the block. Locate the left relocation arm (stamped "L" and "R" on their backsides). On the end with the clearance hole (not threaded) Place the two dowel pins into one of the two sets of holes which are directly across from each other (180 degrees apart). Hold the arm with the dowel pins up to the mounting block. Align the dowel pins with each of the three sets of holes in the block one at a time noting the height of the opposite end of the arm where the floorboard will mount. Move the dowel pins to the other set of holes on the arm and again hold the arm with the dowel pins up to the blocks three sets of holes. Choose the set of holes in both the block and arm which will set the floorboard to the desired height and place the arm with the dowel pins onto the block. Using one of the button head Allen screws supplied bolt the arm to the block and tighten securely.
4. Locate two of the dowel pins supplied and one of the Allen screw removed earlier. Place the dowel pins into the holes of the arm which allow the floorboard to be level or parallel to the ground. Place a drop of loctite on the threads of the screw and tighten securely. Install the right floorboard in the same manner.
5. On the right side remove the floorboard from the mounting block. Remove the mounting block and replace it with the longer one supplied. Install the right arm in the same manner as the left using the set of dowel pin holes to match the height or angle of the left arm. Install the right floorboard and tighten securely. Recheck all fasteners for tightness.

RIVCO Products, Inc.
440 S. Pine St.
Burlington, WI 53105
262-763-8222