

SOLO RACK
FITS ALL TRIUMPH AMERICA & SPEEDMASTER 2006 & OLDER
#TA010

1. Remove the 8mm bolt from the rear of the passenger seat. Remove the passenger seat by pushing the seat forward and lifting up at the front edge of the seat. Remove the 12mm bolt from the rear of the drivers seat.
2. From the supplied hardware locate the two socket head screws and washers, place the large washers onto the screws with the polished side of the washer facing the head of the screws. Place the small screw and washer thru the small hole in the rear of the solo rack, place the black plastic spacer supplied onto the screw on the bottom side of the solo rack. Holding the rack in place on the rear fender, start the screw in the rear hole. Install the remaining large screw with its washer into the front hole and tighten both screws securely.

Note: this solo rack has a load limit of 12 pounds.

Rivco Products, Inc
440 S. Pine St.
Burlington, WI. 53105
Ph. 262-763-8222
rivcoproducts.com