

SWING ARM COVER INSTALLION INSTRUCTIONS
TRIUMPH ROCKET III
TR3015

This cover is designed to fit over the right hand side of the rear suspensions swing arm as follows.

1. Locate and remove the 6mm screw which secures the rear brake hose clip to the top of the swing arm (just in front of the lower right shock absorbers mounting point).
2. Notice the double faced adhesive tape on the inside of the cover and where it will contact the swing arm when installed, clean this area with rubbing alcohol and remove the backing from the adhesive tape on the inside of the cover.
3. Place the ¼” washer provided on the top of the swing arm over the brake hose clip mounting hole. Starting at the rear of the swing arm slide the cover carefully into place and align the small hole in the top of the cover with the washer and the threaded hole. Place the screw thru the hose clip then the cover and finally the washer, next thread the screw into the hole finger tight only.
4. Press the front area of the cover with the adhesive tape firmly into place. Tighten the 6mm brake hose clip screw securely.

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
262.763.8222 rivcoproducts.com