

**INSTALLATION INSTRUCTIONS**  
**TRIUMPH ROCKET III CALIPER COVERS**  
**Front #TR3030    Rear #TR3031**

1. Clean caliper face with rubbing alcohol making sure it is free of grease, oil and debris.
2. If the caliper is below 70 degrees warm it with a hair dryer.
3. Peel the self adhesive backing and press into place firmly and hold for 30 seconds.
4. Repeat with remaining cover if necessary.