

**F3094**  
**Passenger Armrests**  
**For**  
**Can Am Spyder F3 Limited**

1. Lay out and familiarize yourself with the supplied components.
2. Remove the left and right passenger grab handles as follows. Remove the two 8 mm (6mm Allen wrench) bolts from each of the passenger grab handles, remove the handles and set aside.
3. Starting in the Left side and referring to the supplied diagram hold the left armrest assembly up into place. Place one of the supplied spools (A) over the stud then thread one of the supplied 8x30mm Allen bolts with a flat washer into the stud making it finger tight at this time
4. Place another spool over the rear stud as shown followed by the left (marked with an L) arm brace then one of the 8x30 Allen bolts with a flat washer again making it finger tight only. Referring to ( C ) on the diagram install one of the supplied ¼" x ½" Allen screws thru the armrest then the brace followed by one of the supplied acorn nuts and tighten this bolt and nut securely.
5. Install the right armrest in the same manner to this point. Next adjust or slide the armrest assembly back or forward within its slots as desired to position for the passengers comfort. Tighten the four 8x30mm Allen bolts securely.
6. Notice there is an "L" shaped bracket mounted to the bottom of the right armrest pad. This mount will accept Rivco and most other brands of passenger cup holders.



**RIVCO Products, Inc.**

**440 S. Pine St., Burlington, WI. 53105**

**262-763-8222**

*To register your warranty and see many other cruiser and bagger accessories, please visit our website.*

**[www.rivcoproducts.com](http://www.rivcoproducts.com)**

**1**

