

TAIL / FLASHING BRAKE LIGHT MODULE FOR L.E.D. LIGHTS # FLSH

NOTE: THIS MODULE IS FOR USE ONLY WITH L.E.D. LIGHTING

Any use with standard incandescent bulbs will overload and ruin the module!

Using module with incandescent bulbs will void the warranty.

Notice the 2 short green wires coming from the flasher module. Connecting these 2 wires together will make the brake lights flash continuously while the brake is applied. Leaving them separated will make the brake lights flash for 5 seconds & then stay on solid as long as the brake is applied. Be sure to cover the wires with electrical tape.

- 1. Locate a suitable place to mount the module. Inside the tail light housing, trunk or under the seat usually works best. Ensure that the wires will reach the points of connection to the L.E.D. lights as well as the motorcycles tail light wires. Clean the mounting surface with rubbing alcohol, peel the adhesive backing & mount the module. Connect the wires as shown in the wiring diagram. Using the blue butt connectors connect the blue wire from the module to the positive (+) red wires from the L.E.D. lights. Connect the brown wire from the module to the ground (black) wires from the L.E.D.'S.**
- 2. Use the larger red 3-way connectors to connect the gray wire from the module to the motorcycles (+) tail light wire; red wire to the motorcycles (+) brake light wire & the black wire to the motorcycles (-) ground wire. The fork connector can be used to attach the ground wire to the motorcycles frame for the ground if desired.**
- 3. Turn on the ignition switch and check the functions of the L.E.D. lights. The L.E.D. lights should come on with the tail light and when the brake is applied flash as set by the green wire mentioned in step 1. Secure all loose wires with electrical tape or cable ties. Be sure there is no exposure to the wires being pinched, cut, or damaged.**

Warranty. This product is warranted for 1 year from date of purchase to be free from manufacturer's defects. Damage due to modification, improper installation or misuse is not covered. Sellers & manufacturer's only obligation shall be to replace the product proved to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage direct or consequential, arising out of or the inability to use the product for its intended use or user assume all risk & liability, whatsoever in connection therewith.

RIVCO Products, Inc

440 South Pine Street

Burlington, WI 53105

1.262.763.8222

www.rivcoproducts.com

