

HONDA RUNE NRX SPINNER
INSTALLATION INSTRUCTIONS
#NRX500, 501, 502

1. Remove the rear wheel hub center cap. (5 5mm allen screws) Install the new spinner hub using the new screws provided, tighten securely.
2. Place the spinner over the hub until it seats on the hubs base. (you may need to back out the (3) set screws on the spinner so that they are recessed on the inside of the spinner) Tighten the (3) set screws securely.

NOTE: Use extreme caution to make sure no loose clothing, luggage or bungee cords, etc. get caught on the spinner and wrap around the rear wheel.

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
262.763.8222
rivcoproducts.com