PASSENGER FLOORBOARDS
FOR SUZUKI M109
#SM9005

1. Remove the seat. Remove the right plastic side and frame covers as follows. On the right side remove the two (2) 4 mm allen screws from the bottom of the frame and side cover. Remove the plastic push-in rivet from the top forward end of the side cover near the fuel tank (push the center pin of the rivet in or down about ¼" and then pull the entire rivet up out of the cover). Carefully pull the side/frame covers outward at the rear disengaging the pins on the covers from the grommets on the frame there are three pins, one at the rear, bottom and one near the front of the cover. The front of the cover also hooks into a grommet on the fuel tank and must be slid forward to remove the covers.
2. Remove the left side and frame cover as follows. First remove the 4 mm allen screw from the bottom of the side cover, then the plastic rivet on the top forward end of the cover. Pull the bottom of the frame cover outward from the grommet on the frame then like the right side pull out the rear, center and front of the cover and slide it forward to remove it from the grommet on the fuel tank. Leaving the seat lock cable attached lay the cover on top of the frame where you removed the seat.
3. Remove the four (4)12mm bolts which attach the foot pegs and mounting brackets to the frame. Install the two floorboard mounting plates (supplied) using the four (4) original bolts in the rear threaded holes on the frame and the four (4) 8 x 20mm bolts and locking nuts (supplied) in the front holes then tighten all securely.
4. Locate the two round mounting spacers (supplied) notice that one is longer. On the right side using the longer spacer place the pins on one end of the spacer into the mating holes of the mounting plate. Bolt the spacer to the mounting plate using one of the 5/16"x7/8" allen bolts provided and tighten securely. Install the remaining spacer on the left side in the same manner.
5. Re-install the left and right side/frame covers, their mounting screws and plastic rivets. Install the left and right floorboards onto the pins of the spacers (notice they are marked with an L and R on the surface that mates with the spacers) using the set of holes that allows the floorboards to be level or parallel with the ground. Install the two (2) remaining allen bolts (supplied) thru the hole on the floorboard and into the spacer, tighten securely.
6. Re-check to be sure all fasteners are securely tightened. Re-install the seat.

RIVCO Products, Inc
440 S. Pine St.
Burlington, WI. 53105
Ph. 262-763-8222
www.rivcoproducts.com