

**INSTALLATION INSTRUCTIONS
LEFT & RIGHT GRAB HANDLE FOR VALKYRIE
#VAL009LR**

STANDARD & TOURER INSTRUCTIONS

1. Remove the seat.
2. Remove the upper shock bolt
3. Remove the lower backrest bolt.
4. Install the grab rail loosely using the original bolts
5. Tighten securely.
6. Re-install the seat

INTERSTATE INSTRUCTIONS

1. Remove the seat.
2. Remove the upper shock bolt.
3. Put the front end of the grab handle (slotted end) centered on the shock bolt, snug the bolt.
4. Raise the rear hole of the handle to the highest position on the flat, before bend of the trunk support bracket.
5. Mark and drill a ¼" hole.
6. Using the screw and nut provided, attach the rear of the grab handle. Tighten securely.
7. Tighten the shock bolt.
8. Re-install the seat.