

**ELECTRIC HORN INSTALLATION KIT  
FOR VICTORY HAMMER, KINGPIN, VEGAS & JACKPOT  
#EH310**

1. Remove the left and right plastic side covers and the seat (two allen bolts located below the sides of the seat). Unplug and remove the stock horn (located over the oil cooler). Connect the female ends of the jacketed two wire cable supplied to the original horn wires. Route the other end of the cable up over the engine and back to where the relay will mount as shown in photo (1).
2. Using the relay supplied with this kit and the wiring diagram provided with the horn set, identify the terminals of the relay (there are very small numbers next to each of the terminal). Connect the two (2) wires from the cable to terminals #85 & 86 on the relay. Locate the fuse holder wire assembly supplied and connect the blade terminal to the relay terminal #87 or #30. Connect the other end of the fuse wire to the battery positive terminal (+).
3. Working under the left side of the motorcycle, refer to photo (2) and install the black bracket supplied as shown onto the engine mount. Locate the four thin flat brackets and two (2) 6mm nuts supplied with the horn set and two lock washers supplied with the kit. Bolt two (2) of the brackets to each of the horns using a lock washer and 6mm nut on each and make them snug. Using the remaining 6 x 12mm bolt, nut and lock washer install the horns onto the black bracket and align as shown in photo (3). Adjust the horn location so that they are free to vibrate and do not come in contact with other parts of the motorcycle then tighten all three 6mm bolts securely.
4. Using the two remaining wire assemblies supplied, connect the larger terminals with double wires to one of the horns and the terminals with the single wire to the other horn. Route these wires up thru the frame to the relay. Connect the wire with the female blade connector to the relay terminal #30 or #87. Connect the ring terminal to the battery negative (-) terminal or any 6m bolt on the frame. Turn on the ignition and test the horns. Secure the relay to the frame or other wiring and all loose wires using the cable ties supplied. Replace the seat and side covers.

RIVCO Products, Inc  
440 S. Pine St.  
Burlington, WI 53105

Ph. 262-763-8222    [www.rivcoproducts.com](http://www.rivcoproducts.com)



